



# **Light Controls**

## **Product Assortment**

- Light Sensing
- Dimmers and
- Motion Activated
- **Touch Controls**
- Wireless

## **Light Sensing Technology**

- On and Off control triggered by ambient light level
- Automatically adjusts to seasonal changes in daylight
- Screw-In, Plug-In and Wire-In installation options



### What is a Light Sensor?

A light sensor reads and reacts to ambient light levels, and responds to those light conditions by turning a light on or off. Westek Light Sensing Controls turn power to a light or device on or off depending on the ambient lighting conditions as detected by the photo sensor. It is a simple, affordable, and user friendly way to control your lights throughout the year. Several variaties are offered for screw-in, plug-in, and wire-in installation, as well as models that offer advanced features and programming options.

## **Motion Activated**

- Activated by motion when someone enters the room / sensing area.
- Turns off after motion stops.
- Screw-In & Plug-In installation options



### What is a Motion Activated Light Control?

A motion activated light control turns lights / devices on or off when motion is detected. Some models offer a fixed off-time, while others offer users the ability to customize how long the light remains on after motion stops. Several variations are offered for indoor use, porch use, and both screw-in and plug-in installation options are offered.

## **Wireless Technology**

- Allows remote control on/off of lights and small household devices
- Use wall switch or handheld remote to wirelessly turn power on or off
- Indoor and Outdoor varieties work up to 100' away



## What is a Wireless Remote Control outlet?

A wireless remote control outlet offers users a convenient way to turn their lamps and other devices on and off from across the room, house or yard. Plug your lamp or device into the plug-in receiver, and then use the wireless handheld remote or wall switch to power that device on or off from up to 100' away.

## **Dimmers & Touch Controls**

- Allow easy plug & play dimming of lamps and light fixtures
- Works with incandescent and many dimmable LED bulbs
- Full range and 3-level dimming.
   Screw-In, Plug-In and Wire-In Options



### What are Dimmers and Touch Controls?

Dimmers and touch controls allow users an easy, cost-effective and DIY way to add dimming functions to their lamps. Choose the right light level to set the mood or perform the task at hand. Select from full range dimming, 3 level touch dimming or simply on/off control. Installation options include screw-in, plug-in and wire-in offerings.



Indoor

## **Motion Activated**

### MLC12BC-4 PLUG-IN MOTION ACTIVATED LIGHT CONTROL

## Indoor

• On when motion detected, off after 1, 2, 5, 10 or 20 minutes

- · Detects motion up
- to 25' away
   100° detection zone





#### Indoor MLC2BC 75W MOTION ACTIVATED LIGHT CONTROL

 Automatically turns light on when motion is detected off 10 minutes after you leave



UPC: 07068650435-2

#### Indoor MLC4BC PLUG-IN MOTION ACTIVATED LIGHT CONTROL

- On when motion detected, off after 1, 2, 5 10 or 20 minutes · Detects motion up
- to 25' away

   100° detection zone
- UPC: 07068650702-5



### 75W MOTION ACTIVATED LIGHT CONTROL Automatically turns light

on when motion is detected, off 1, 2, 5, 10 or 20 minutes after you leav

· Detects motion up to 30' away

MLC6BC

UPC: 07068650720-9



 Automatically turns light on when motion is detected, off 10 minutes after you leave

· Detects motion up to 20' away UPC: 07068650693-6



#### Outdoor OMLC3BC-4 PORCH MOTION ACTIVATED LIGHT CONTROL

- · Automatically turns light on when motion is detected, off 10 minutes motion stons
- Detects motion up to 30' away

UPC: 07068650563-2



- Automatically turns light on when motion is detected, turns off 1, 2, 5, 10 or 20 minutes after motion stops

Outdoor

Detects motion up to 30' away

UPC: 07068650721-6

#### Outdoor OMLC7BC PORCH MOTION ACTIVATED LIGHT CONTROL

- Automatically turns light on at dusk, off after 2, 5 or 8 hours as selected by user
   Automatically turns light
- back on when motion is detected, turns off 10 minutes after motion stops

UPC: 07068650722-3

### MLC18BC 4 IN 1 WIRFI FSS LIGHT CONTROL

- · All Day motion
- Night Time motion
   Dusk to Dawn

## Indoor

- Random

UPC: 07068650870-1

# **Dimmers and Touch Controls**

### 4009BC-2 FULL RANGE DIMMER WITH DELAY OFF

- · Converts any lamp to
- full range dimming Full Range Control
- Memory Feature

UPC: 07068650551-9



- · Converts any lamp to full range dimming
- Full Range Control

• Plug-In



Indoor

Indoor

### 4010W TABLE TOP LAMP DIMMER

- Converts any lamp to full
- range dimming

• Plug-In

UPC: 07068649232-1

## Indoor

- Full Range Control



## Compact size allows access to other outlets

6000BC

PLUG-IN TOUCH

ON/OFF CONTROL

Touch any metal part

of the lamp for easy On and Off

IIPC: 07068650550-2

#### 6004B PI UG-IN

- TOUCH DIMMER • Converts lamp to 3-way touch control
- Touch any metal part of lamp for 3 levels of brightness



Indoor

Indoor

UPC: 07068649114-0

MANUAL DIMMER

REPLACEMENT KIT

6079BC

### 6009B **FULL RANGE**

- DIAL DIMMER Converts any lamp to
- full range dimming Full range dimming from dim to bright

FOOT CONTROL

LAMP DIMMER

Easy to use slide control

Slide type control for full range dimming

UPC: 07068649104-1

converts any lamp to full range dimming

• Heavy duty long life design



Indoor

Indoor

UPC: 07068649100-3

### 6043BC TOUCH PAD DIMMER

• Touch any part of lamp for 3 levels of brightness

UPC: 07068649113-3

FOOT CONTROL

LAMP DIMMER

• Easy to use slide control

converts any lamp to full range dimming

Slide type control for full range dimming

UPC: 07068649105-8

Heavy duty long life design

6089WB

## Indoor



## 6043C

- Touch the decorative snowflake omament to
- · Easy and convenient to

UPC: 07068649116-4

6503BC

## Indoor HOLIDAY ORNAMENT TOUCH DIMMER

- turn tree lights On/Off or 3 levels of brightness

use, just plug-in

REPLACEMENT KIT

TOUCH DIMMER

Universal replacement kit

Works in any touch lamp

• 3 Level Control

UPC: 07068649102-7



Indoor

## 6503HBLC

- Works in any
- touch lamp

UPC: 07068649103-4

#### Indoor 6077B MANUAL DIMMER REPLACEMENT KIT

- Universal replacement kit For halogen or incandescent bankers
- lamps and wall sconces

Full Range Control

Indoor

### • Universal replacement kit For halogen or incandescent floor lamps and torchieres Full Range Control UPC: 07068649108-9

## UPC: 07068649110-2

### Indoor REPLACEMENT KIT

- TOUCH DIMMER Universal replacement kit

3 Level Control

## 6603BC

- TOUCH DIMMER Converts metal socket lamp to 3-level touch
- control Touch any metal part of lamp for 3 levels of brightness

UPC: 07068649115-7



Indoor

## 6702BC







Outdoor

## **Light Sensing**

## 758CTC-4 POST EYE LIGHT CONTROL

- Turns lights on at dusk, off at dawn
- For lamp posts and light fixtures
- CFL/LED Compatible
- 3/8"-1/2" Knockout



### Outdoor 758FPCTCC-4 LIGHT CONTROL

- Turns lights on at dusk, off at dawn
- Fits conduit box (T-box or FS type) Weather-resistant sealed photocell

UPC: 07068649023-5



Indoor

Outdoor

Outdoor

## LIGHT CONTROL

• Turns lights on at dusk, off at dawn

Outdoor

Outdoor

Outdoor

- For lamp posts and light fixtures
- CFL/LED Compatible • 7/16" diameter opening
- UPC: 07068650814-5

### AT15BC-4 STEM MOUNT LIGHT CONTROL

- Turns lights on at dusk, off at dawn
- Operates incandescent, LED, fluorescent, mercury vapor and sodium fixtures

UPC: 07068649024-2



# off at dawn

AT15SW-4

SWIVEL STEM

 Standard 1/2" pipe thread with swivel base • Weatherproof housing and lens

Turns lights on at dusk,

UPC: 07068650801-5

SLC2BCB3-4



Outdoor

### CL11LC DUSK-TO-DAWN LIGHT CONTROL

- Turns lights on at dusk, off at dawn
- floor or swag lamps UPC: 07068649014-3

# Indoor

Outdoor

### CL12BC-2 **PROGRAMMABLE** LIGHT CONTROL

- Turns lights on at dusk, off after 2, 5, 8 hours or at dawn
- Random feature discourages intruders Indoor use

UPC: 07068650423-9



#### Outdoor LC120BC-4 TWIST LOCK LIGHT CONTROL

- . Turns lights on at dusk
- Twist Lock
- CFL/LED Compatible Time delay feature eliminates annoying flicker

UPC: 07068649015-0

### OLC5CFLBC-4 FLOODLIGHT LIGHT CONTROL

- Turns lights on at dusk, off at dawn
- Ideal for driveways, entrances and patio lights
- Just screws in no wiring!

UPC: 07068650565-6



Outdoor

SLC5BCB-4

## CANDELABRA LIGHT CONTROL Turns candelabra- based incandescent bulbs on at dusk, off at dawn

 Spring loaded contact allows for sensor orientation

UPC: 07068650442-0

### Plug-in Indoor use • For use with table,

### SLC4CB-4 DUSK TO DAWN LIGHT CONTROL

- Turns incandescent lights on at dusk, off at dawn
- Just screws in no wiring!

UPC: 07068650559-5

## SLC4CG DUSK TO DAWN LIGHT CONTROL

- Turns incandescent lights on at dusk, off at dawn

 Just screws in no wiring!

UPC: 07068649006-8

## SLC4CPL DUSK TO DAWN LIGHT CONTROL Turns incandescent

- lights on at dusk, off at dawn Just screws in -
- no wiring!

UPC: 07068649008-2

### SLC4CW DUSK TO DAWN LIGHT CONTROL

- Turns incandescent lights on at dusk, off at dawn
- Just screws in no wiring!



Outdoor

## UPC: 07068649007-5

## SWIVEL MOUNT

- CFL/LED
- Compatible



## Outdoor

## **DUSK TO DAWN** CFL LIGHT CONTROL

- Turns incandescent lights on at dusk, off at dawn
- Just screws in no wiring!

UPC: 07068650566-3



Outdoor

#### Outdoor SLC5BCW-4 DUSK TO DAWN

- CFL LIGHT CONTROL Turns incandescent
- lights on at dusk, off at dawn lust screws in -

UPC: 07068650564-9

### SLC6CBC-4 **PROGRAMMABLE** LIGHT CONTROL

- Programmable off-timer
- from 2, 5 or 8 hours Dusk-to-dawn default
- Random off feature

discourages intruders UPC: 07068649225-3



Indoor

1

### SLC9BC PROGRAMMABLE LIGHT CONTROL

- Turns lights on at dusk, off after 2, 5, 8 hours or at dawn
- Retains programmed settings in power outage

UPC: 07068650725-4

## SW103CTC-4 LIGHT CONTROL

- Turns lights on at dusk, off at dawn • Plug-in

UPC: 07068649020-4



## Wireless

### RFK100LC WIRELESS WALL MOUNTED SWITCH AND PLUG-IN RECEIVER

- Add the convenience of a wall switch without any wiring
- Works up to 100 ft. away even around corners!

IJPC: 07068649217-8

## RFK106LC WIRELESS REMOTE CONTROL SYSTEM

- Control lights and appliances from inside or outside your home without any wiring
- just plug-inWorks up to 100 ft. away even around corners!

IIPC: 07068649219-2

### Indoor RFK136LC WIRELESS REMOTE CONTROL SYSTEM 3PK

- Control lights and appliances from inside or outside your home without any wiring 1.0.
- just plug-in Works up to 100 ft. away

 even around corners! UPC: 07068650817-6

## RFK306LC

- Control lights and appliances from inside or outside your home without any wiring just plug-in
- just plug-inWorks up to 80 ft. away

UPC: 07068650703-2

## Outdoor WIRELESS REMOTE AND PLUG-IN RECEIVER





# Notes

Model	Description	Shelf	Case	UPC	Model	Description	Shelf	Case	UPC
4009BC-2	DELAY OFF DIMMER 2/24	2	24	070686505519	MLC12BC-4	INDOOR PLUG IN MOTION ACT	4	48	070686506943
4010L	300W, BLACK, TABLE TOP LAMP DIMMER	5	50	070686504086	MLC18BC	4 IN 1 WIRELESS LIGHT CONTROL	2	12	070686508701
4010W	300W WHITE TABLE TOP LAMP DIMMER	5	50	070686492321	MLC2BC	75W MOTION ACTIVATED LT CONTROL	4	24	070686504352
6000BC	200W PLUG-IN TOUCH ON/OFF CTRL 6/CC	6	60	070686505502	MLC4BC	PLUG IN MOTION ACT 4/48	4	48	070686507025
6004B	200W PLUG-IN TOUCH DIMMER	5	50	070686491140	MLC6BC	IND MOTION ACTIVATED W ADJ OFF TIMES	4	16	070686507209
6009B	100W MANUAL DIMMER	5	50	070686491003	MLC9BC-4	IND MOTION ACT 360	4	48	070686506936
6043BC	200W 3-LEVEL TOUCH PAD DIMMER, 6/CC	6	60	070686491133	OLC5CFLBC-4	FLOODLIGHT LC CFL	4	48	070686505656
6043C	HOLIDAY 200W 3-LEV, TOUCH PAD DIMMER	5	20	070686491164	OMLC3BC-4	PORCH MOTION ACT LC	4	48	070686505632
6077B	200W MANUAL REPLACEMENT DIMMER	5	50	070686491102	OMLC5BC	PORCH MOTION ACT W ADJ OFF TIMES	4	16	070686507216
6079BC	500W MANUAL DIMMER REPL. KIT, 6/CC	6	60	070686491089	OMLC7BC	DUAL FUNCTION SECURITY LIGHT CONTROL	4	16	070686507223
6089B	500W BLACK, FOOT CONTROL DIMMER	5	50	070686491041	RFK100LC	RF WALL TRANS & PL-IN REC KIT, 4/CC	4	16	070686492178
6089WB	500W WHITE, FOOT CONTROL DIMMER	5	50	070686491058	RFK106LC	RF KEYFOB TRANS&PLUGIN REC KIT,4/CC	4	40	070686492192
6503BC	150W H-W, TOUCH DIM REPL. KIT, 6/CC	6	60	070686491027	RFK136LC	WIRELESS KEY FOB 3PK RECEIVER KIT	4	16	070686508176
6503HBLC	300W H-W TOUCH DIM REPL. KIT, 5/CC	5	50	070686491034	RFK306LC	<b>OUTDOOR WIRELESS REMOTE 4/24</b>	4	24	070686507032
6603BC	150W SCREW-IN TOUCH DIMMER, 6/CC	6	60	070686491157	SLC2BCB3-4	CANDELABRA LC BRONZE 4/48	4	48	070686504420
6702BC	150W SCREW-IN TOUCH ON/OFF CNTRL 6CG	6	60	070686504499	SLC4CB-4	DUSK / DAWN LC BLACK 4/48	4	48	070686505595
758CTC-4	POST EYE LC 4/48	4	48	070686490181	SLC4CG	150W GRAY, IN/OUTDOOR LIGHT CONTROL	5	50	070686490068
758FPCTCC-4	FACE PLATE LC 4/48	4	48	070686490235	SLC4CPL	150W BRASS,IN/OUTDOOR LIGHT CONTROL	5	50	070686490082
758M	MINI POST EYE LC 4/16	4	16	070686508145	SLC4CW	150W WHITE, IN/OUTDOOR LIGHT CONTROL	. 5	50	070686490075
AT15BC-4	STEM MOUNT LC 4/48	4	48	070686490242	SLC5BCB-4	DUSK TO DAWN LC, CFL, BRZ	4	48	070686505663
AT15SW-4	SWIVEL STEM MOUNT LC 4/48	4	48	070686508015	SLC5BCW-4	DUSK TO DAWN LC, CFL, WHT	4	48	070686505649
CL11LC	300W INDOOR PLUG-IN LT CNTRL, 5/CC	5	50	070686490143	SLC6CBC-4	PROGRAMMABLE LC 4/48	4	48	070686492253
CL12BC-2	IND PROG LIGHT CONTROL	2	20	070686504239	SLC9BC	PROGRAMMABLE LIGHT CONTROL	4	16	070686507254
LC120BC-4	TWIST LOCK LC 4/48	4	48	070686490150	SW103CTC-4	SWIVEL MOUNT LC 4/48	4	48	070686490204

